

- 1. 1/2" COMPRESSIBLE MATERIAL ALL AROUND.
- 2. SEE MECHANICAL DRAWINGS.
- 3. SEE PLAN.
- 4. #4 AT 12" O.C. EACH WAY TOP AND BOTTOM.

## NOTES:

- A. EQUIPMENT FOOTING TO EXTEND 6" MIN. BEYOND EDGE OF M.P.E. EQUIPMENT ON ALL SIDES.
- B. SEE M.P.E. AND ARCHITECTURAL. DRAWINGS FOR EQUIPMENT LOCATIONS.
- C. PROVIDE ANCHOR BOLTS FOR EQUIPMENT AS REQ'D. BY EQUIPMENT MFR.



## MECHANICAL EQUIPMENT PAD DETAIL

| REV. NO.    | 001      | DWG. NO. |        |
|-------------|----------|----------|--------|
| REV. DATE : | 10-13-20 |          | MP-203 |
| DRAWN BY:   | NBS      | SCALE:   | NTS    |