


SRP M-POWER

USER'S MANUAL



Please read this manual carefully
before operating your SRP M-Power® equipment.



Delivering more than power.™

Table of Contents

Important Things You Should Know About M-Power	2
Getting Started — Setting Up M-Power	2
Using M-Power	5
▶ The M-Power Display Unit	5
▶ Purchasing Energy	6
▶ Loading Energy Credit on Your Meter	7
▶ Installing and Replacing Batteries	8
▶ Restoring Power	9
▶ Friendly Credit	9
▶ Emergency Credit	10
Answering Your Questions	11
Display Unit Information	12
Troubleshooting Guide	13

IMPORTANT THINGS YOU SHOULD KNOW ABOUT M-POWER

With SRP M-Power, you have more control of your energy usage than ever before. Now you have the ability to track how much energy you use and decide when and how much energy to buy.

To make sure you enjoy the many benefits that SRP M-Power has to offer, here are some things you need to know:

1. **Your M-Power system features “Friendly Credit.”** Friendly Credit will keep your power from disconnecting if you run out of energy credit late at night. Read more about Friendly Credit on Page 9.
2. **Outside of Friendly Credit time periods, your electricity will turn off if your credit reaches zero dollars.** Be sure to check your remaining credit balance regularly. Always keep at least four days of credit on your meter at all times.
3. **Your M-Power system features “Emergency Credit.”** Emergency Credit is for times you are unable to make an energy credit purchase because of problems with an SRP PayCenter®. Read more about Emergency Credit on Page 10.
4. **Your User Display Terminal (UDT) is the property of SRP and must be returned if you discontinue M-Power service.** If you don't return the display unit when discontinuing M-Power service, SRP will charge your account for the display unit.

GETTING STARTED — SETTING UP M-POWER

Once your meter is installed, you need to complete the following steps immediately:

1. **Check the contents of your M-Power kit.**
The kit should contain the items listed below. Contact SRP at (602) 236-8855 if any of the items are missing. Make sure you discard packing materials such as tape, plastic, wire ties and tags properly to protect children and pets.

- (1) SRP M-Power display unit
- (1) 9-volt alkaline battery
- (1) SRP PayCenter locations map

2. **Install the 9-volt battery located in your M-Power kit in the display unit.** See “Installing and Replacing Batteries” on Page 8 for more details.

3. **Plug display unit into an electrical outlet.**

Do not use a surge protector, ground fault interrupter (GFI) outlet, wall-switch-operated outlet or any outlet near water.

4. **Select your language.**

Press the “Select Language” button on the front of the display unit to choose either English or Spanish.



Display Unit Buttons

5. **Connect display unit with meter.**

When the display unit turns on, the message “Insert Card To Connect To Meter” will appear. When this message appears, do the following:

- A. Insert an M-Power Smart Card into the display unit with the gold chip and arrow face up. The message will change to “Communicating With Meter.” While this message appears, the display unit and meter are connecting.



Insert Smart Card

B. When the meter and display unit are connected, the message will change to "Please Wait, Processing Card" followed by "Card Processed." The credit amount, if any, that has been loaded onto the meter will also appear. Then the message will change to "SRP M-Power," indicating that the process is complete.

C. Remove the Smart Card.

6. **Purchase energy credit.**

SRP placed a small energy credit on your meter to get you started. However, it will last the average household only a few days. You must now purchase energy credit at any SRP PayCenter. See the enclosed map or visit www.srpnet.com/paycenters for locations of SRP PayCenters. After the purchase, insert your Smart Card that contains the energy credit face up into the display unit. The credit will transfer onto the meter.

SRP PayCenter



USING M-POWER

THE M-POWER DISPLAY UNIT

Your M-Power display unit shows information that can help you gain control of your energy usage. The two buttons on the front of the M-Power display unit will let you do the following things:



Display Unit Buttons

1. **Select a language.**

You can have the display unit information appear in either English or Spanish by pressing the “Select Language” button.

2. **View display information.**

When you press the “Display Cycle” button, you can view each of the display unit’s information screens. The three displays that will be the most useful to you in managing your energy usage are described below. Just press the “Display Cycle” button until the display you want to see appears.

- **Remaining Credit Is \$XX.XX**

This screen shows the dollar amount of your remaining energy credit.

- **Enough Credit For “X” Day(s)**

This screen shows an estimate of the number of days remaining before your energy credit runs out.

NOTE: For the first week after your M-Power system is installed, the “Enough Credit For X Day(s)” screen will read “???” or “100 days.” This is normal. The system takes approximately a week to monitor how much electricity you typically use per day. After the first week, the “number of days remaining” information will be based on your consumption during the previous seven days.

NOTE: There is a three- to four-second delay when the display unit updates the “Remaining Credit” and “Enough Credit For X Day(s)” screens. First you will see the amount from the last time you checked the display, then the updated amount. The change reflects the amount of energy you used since you last checked the screen.

- **Cost Per Hour Is \$X.XX**

This screen shows the amount of energy you are using expressed in dollars per hour.

- You can find a list and brief description of the information on your display on Page 12.

3. **Load Emergency Credit.**

Press the “Select Language” and “Display Cycle” buttons at the same time to load Emergency Credit to your meter. See Page 10 for more information about Emergency Credit.

PURCHASING ENERGY

With SRP M-Power, you decide when to buy, where to buy and how much energy to buy.

When to Buy

1. **Check your display unit often.**

SRP recommends that you purchase additional energy credit when only four days of credit remain on your meter.

2. **Immediately purchase energy credit if “WARNING: Low Credit” appears on the display unit.**

About four days before your energy credit runs out, the “WARNING: Low Credit” message will appear and a double beep will be heard. The warning beep may be turned off by pressing the “Display Cycle” button. The “WARNING” message will continue to appear until you add more than four days’ worth of energy credit to the meter.

IMPORTANT: Keep a few days of energy credit on one of your Smart Cards at all times to avoid running out of power.

Where to Buy

You can purchase energy at any SRP PayCenter. Check the map included in your M-Power Kit or visit www.srpnet.com/paycenters for the location nearest you.

How to Buy

1. **Visit any SRP PayCenter.**
Don't forget to take your Smart Card with you each time you want to make a purchase.
2. **Select the M-Power payment choice on the SRP PayCenter menu screen.**
3. **Follow the voice and word instructions.**

LOADING ENERGY CREDIT ON YOUR METER

After you make your energy credit purchase, follow these simple steps to load the credit on your meter:

1. **Insert the Smart Card containing the energy credit you purchased face up into the slot on the right side of your display unit.** The display unit will indicate "Please Wait – Processing Card."
2. **When the credit has loaded onto your meter, the message will change to "Card Processed" and the amount of credit loaded on your meter will appear. You'll hear multiple beeps, which tell you that the transaction was successful. Remove your Smart Card when the "SRP M-Power" message appears.** This process should take about 45 seconds.

IMPORTANT: If you remove the Smart Card from the display unit too soon, the credit will not transfer to your meter. If the message "Please Insert Your Card!" appears, your card was removed too soon. Reinsert your card and wait until the "Please Wait – Processing Card" message no longer appears and you hear a beep.

IMPORTANT: If the message “Credit \$XX.XX Pending” appears, the credit did not load to your meter. You may not use any other Smart Card in your display unit until the credit has been successfully loaded onto your meter. Please check the Troubleshooting Guide in the back of this manual for more details if this happens.

NOTE: Energy credit will accumulate on Smart Cards that have not been inserted in the display unit and loaded on the meter.

As an example, if you have a \$10 energy credit on your Smart Card and then purchase an additional \$10 of credit, you will have \$20 of credit waiting to be loaded on your meter.

INSTALLING AND REPLACING BATTERIES

You will need to install the 9-volt battery in the display unit before using M-Power. Occasionally, the battery will also need to be replaced. To install or replace the battery, follow these steps:

1. Make sure the display unit is unplugged.
2. Remove the battery cover on the back of the display unit. Install the 9-volt alkaline battery.
3. Place the battery cover back on the display unit.

NOTE: SRP recommends using alkaline batteries. If needed, clean any corrosion on battery clips with rubbing alcohol and a cotton swab. We do not recommend using rechargeable batteries.



Display Unit Back View

RESTORING POWER

If you run out of credit and your electricity turns off, do the following:

1. Make sure that you have a new 9-volt battery installed in the display unit.
2. Turn on the display unit by pushing and holding the "Display Cycle" button on the front of the display unit.
3. While holding down "Display Cycle," insert a Smart Card with energy credit into the display unit. Remember that you can purchase energy credit at any SRP PayCenter location.
4. Wait for the power to turn on. If your power does not turn on, repeat Steps 1–3.
5. If your power doesn't turn on after two attempts, do the following:
 - Check that your circuit breakers are in the "on" position.
 - Make sure you have a new 9-volt alkaline battery properly installed in the display unit.
 - Make sure the display unit is not plugged into a surge protector, GFI outlet or wall-switch-operated outlet.
 - Check that lights are on in your neighborhood. There may be a power outage in your area.

FRIENDLY CREDIT

This feature will allow your power to stay on if you run out of energy credit late at night. See the insert that was included with your M-Power kit for the times Friendly Credit is available. **Hours are subject to change. Check the quarterly *Contact* newsletter mailing for updated Friendly Credit hours.**

Here are some important reminders about Friendly Credit.

1. During Friendly Credit hours, your electricity will not shut off if you run out of energy credit. You will need to purchase and load

energy credit before the Friendly Credit period ends or your electricity will shut off.

2. While on Friendly Credit, your meter will keep track of the amount of energy you use. When you insert your Smart Card with energy credit into your display unit, it will immediately subtract the energy use from the Friendly Credit period. Then the display will begin subtracting your current energy use.
3. If you run out of energy credit before the Friendly Credit period begins, you will need to purchase additional credit to restore your power.
4. If your electricity turns off before you load any energy credit, you will need to turn on your display unit before loading the credit. Just press the "Display Cycle" button on the front of the display unit and then insert your Smart Card containing the credit.

EMERGENCY CREDIT

This feature can be activated in the unlikely event of a widespread failure of the SRP PayCenter network that prevents you from buying energy credit.

To obtain Emergency Credit, do the following:

1. Call SRP at (602) 236-8855. The SRP representative will give you a 16-digit activation number (eCode) that will need to be entered on the display unit. Write this number on a piece of paper.
2. After your energy credit runs out and your power turns off, press both the "Select Language" and "Display Cycle" buttons on the display unit at the same time for five seconds. The message "Enter Your eCode" will appear. Your electricity will turn on for 10 minutes while you enter the code.

IMPORTANT: Your power must have turned off to operate the Emergency Credit feature.

3. Begin entering the code number by pressing the "Select Language" button until the first number you need appears. Then press the "Display Cycle" button to lock in the number and move to the next position. If you make a mistake entering a number, press both buttons for two seconds and release. The blinking line will move back to the last digit entered, so you can correct the entry.
4. Repeat Step 3 until all 16 digits have been entered. The message "eCode Accepted" will appear if the number has been entered correctly and validated. Once entered, your electricity will remain on for the amount of time specified by SRP when you called for the code.

WARNING: You have five attempts to enter the code in 10 minutes. If the code has not been entered correctly after five attempts, the meter will disconnect. You must wait one hour before trying again. You can attempt to enter the code a maximum of five times per day. You will be charged for the time the electricity remains on while attempting to enter the code number.

WARNING: While your meter is using Emergency Credit, it will keep track of the amount of energy you use. When you are able to make your next energy credit purchase and load it to your meter, the amount of energy you used during that time will be deducted from the purchased credit amount.

ANSWERING YOUR QUESTIONS

Call SRP at (602) 236-8855 if you have any questions. An SRP representative will assist you.

DISPLAY UNIT INFORMATION

ENGLISH	DESCRIPTION
SRP M-Power (602) 236-8855	Introductory message
Remaining Credit Is \$XX.XX	The dollar amount of your remaining energy credit
Accumulated Debit Is \$XXX.XX	The dollar amount of accumulated charges after all energy credit has been used and "Emergency" or "Friendly" credit mode is active
Enough Credit For XXX Day(s)	The estimated number of days remaining before your energy credit runs out
Cost Per Hour Is \$XX.XX	The amount of energy you have used in the last hour expressed in dollars
Present Electric Demand X.X kW	The amount of energy you are currently using measured in kilowatt (kW) hour(s)
Cost Today Is \$XX.XX	The amount of energy you have used since midnight expressed in dollars
Cost Yesterday Was \$XX.XX	The amount of energy you used yesterday expressed in dollars
Cost This Month Is \$XX.XX	The amount of energy you used since the beginning of the month expressed in dollars
Cost Last Month Was \$XXXX.XX	The amount of energy you used last month expressed in dollars
Rate # Electric Is	The current rate being used to calculate energy charges and the accumulated energy used for that rate
XXXXXXX.XX kWh	Rate 1 = standard rate or off-peak (Time-of-Use), Rate 2 = on-peak (Time-of-Use)
Rate # Charge Is \$X.XXXX/kWh	The price you pay per kilowatt-hour (kWh) of electricity for rate plan indicated: Rate 1 = standard rate or off-peak (Time-of-Use), Rate 2 = on-peak (Time-of-Use)
Total Usage XXXXXX.XX kWh	Shows total kWh accumulated on the meter (may be used by SRP for troubleshooting purposes)

TROUBLESHOOTING GUIDE

If you experience a problem with your M-Power system, try the steps below before calling SRP.

DISPLAY UNIT MESSAGES

MESSAGE	CAUSE
Already used, please remove	<ul style="list-style-type: none">• Smart Card already used.• Using wrong Smart Card.• Last purchase did not get loaded on Smart Card.
SOLUTION	<ul style="list-style-type: none">• Use a Smart Card that contains energy credit or purchase energy credit at any SRP PayCenter.• Try all of your Smart Cards to make sure the correct one is being used.• If you think your last purchase was not loaded on your Smart Card, call SRP Customer Service at (602) 236-8855 for assistance.
Bad card	<ul style="list-style-type: none">• Information on Smart Card is incorrect or missing.• Smart Card(s) damaged.• Smart Card expired.
SOLUTION	<ul style="list-style-type: none">• Try other Smart Cards in your possession.• Visit an SRP Customer Service Office to replace Smart Cards.
Battery low, please replace	<ul style="list-style-type: none">• Power has been disconnected.• Battery in display unit is dead, weak, missing or improperly installed.
SOLUTION	<ul style="list-style-type: none">• Check that battery is properly installed.• Replace battery. Install a new 9-volt alkaline battery in display unit. If necessary, clean any corrosion on clips with rubbing alcohol and a cotton swab.

MESSAGE	CAUSE
Blank/no message	<ul style="list-style-type: none"> • Display unit not properly plugged in. • Power is disconnected and battery in display unit is dead, weak, missing or improperly installed.
SOLUTION	<p>If you have power in the house:</p> <ul style="list-style-type: none"> • Check that the wall outlet is working by testing with another appliance. • Check that the display unit is not plugged into a GFI, surge protector or switch-controlled outlet. • Check that the plug is not loose. • Check all circuit breakers. Reset if necessary. • Relocate the display unit to another outlet in home. Push blue "Display Cycle" button. Reinsert last Smart Card. • If display unit remains blank, visit an SRP Customer Service Office to replace display unit. <p>If you do not have power on in the house:</p> <ul style="list-style-type: none"> • Check circuit breakers. Reset if necessary. • Replace the battery. Place a new 9-volt alkaline battery in the display unit. If necessary, clean any corrosion on battery clips with rubbing alcohol and a cotton swab. • Relocate the display unit to another outlet in home. Push blue "Display Cycle" button. Reinsert last Smart Card. • If display unit remains blank, visit an SRP Customer Service Office to replace display unit.
Can't read meter, please try later	<ul style="list-style-type: none"> • Bad connection between display unit and meter.
SOLUTION	<ul style="list-style-type: none"> • Check that the wall outlet is working by testing with another appliance. • Relocate the display unit to another outlet in home. Push blue "Display Cycle" button. Reinsert last Smart Card. • If error message continues, visit an SRP Customer Service Office to replace display unit.
Card not for this unit	<ul style="list-style-type: none"> • Wrong Smart Card used. • Information on Smart Card is incorrect or missing.
SOLUTION	<ul style="list-style-type: none"> • Try other Smart Cards in your possession. • Visit an SRP Customer Service Office to replace Smart Cards.
Card too old, return to office	<ul style="list-style-type: none"> • Smart Card has expired.
SOLUTION	<ul style="list-style-type: none"> • Check date and time on display unit. • If date and time incorrect, call SRP Customer Service at (602) 236-8855 for assistance. • If date and time correct, visit an SRP Customer Service Office to replace Smart Cards and UDT.

MESSAGE	CAUSE
Check that display unit is plugged in	<ul style="list-style-type: none"> • Power to the display unit has been disconnected. • Display unit is operating on battery power.
SOLUTION	<ul style="list-style-type: none"> • Check that the wall outlet is working by testing with another appliance. • Check that the display unit is not plugged into a GFI, surge protector or switch-controlled outlet. • Check that the plug is not loose. • Reinsert last Smart Card into display unit.
Communication problems	<ul style="list-style-type: none"> • Bad connection between display unit and meter. • Display unit not properly plugged in.
SOLUTION	<p>If you have power in the house:</p> <ul style="list-style-type: none"> • Check that the wall outlet is working by testing with another appliance. • Check that the display unit is not plugged into a GFI, surge protector or switch-controlled outlet. • Check that the plug is not loose. • Check all circuit breakers. Reset if necessary. • Relocate the display unit to another outlet in home. Push blue "Display Cycle" button. Reinsert last Smart Card. • If display unit remains blank, visit an SRP Customer Service Office to replace display unit. <p>If you do not have power on in the house:</p> <ul style="list-style-type: none"> • Check circuit breakers. Reset if necessary. • Replace the battery. Place a new 9-volt alkaline battery in the display unit. If necessary, clean any corrosion on battery clips with rubbing alcohol and a cotton swab. • Relocate the display unit to another outlet in home. Push blue "Display Cycle" button. Reinsert last Smart Card. • If display unit remains blank, visit an SRP Customer Service Office to replace display unit.
Credit full, try card later	<ul style="list-style-type: none"> • The Smart Card being inserted has energy credit that, if loaded, will exceed the maximum amount allowed.
SOLUTION	<ul style="list-style-type: none"> • Wait several days until energy credit on meter is used. • Try again to load energy credit from your Smart Card.
Credit \$XX.XX pending	<ul style="list-style-type: none"> • Attempts to communicate with meter have failed. • Energy credit from current Smart Card is waiting to be transferred to meter.
SOLUTION	<ul style="list-style-type: none"> • Reinsert Smart Card to re-establish contact. • Try other Smart Cards in your possession. • Visit an SRP Customer Service Office to replace Smart Cards.

MESSAGE	CAUSE
Credit pending, try card later	<ul style="list-style-type: none"> • Attempts to communicate with meter have failed. • Energy credit from current Smart Card is waiting to be transferred to meter.
SOLUTION	<ul style="list-style-type: none"> • Insert Smart Card into display unit. • Hold both buttons on display unit down. "Credit Pending" and "Try Card Later" messages will appear. Continue holding buttons for one to two minutes until credit loads. • If unsuccessful, call SRP Customer Service at (602) 236-8855 for assistance.
eCode used or attempts limited	<ul style="list-style-type: none"> • Emergency code has already been used or number of attempts has reached limit.
SOLUTION	<ul style="list-style-type: none"> • If unsuccessful, call SRP Customer Service at (602) 236-8855 for assistance.
Insert card to connect to meter	<ul style="list-style-type: none"> • Display unit and meter have not been linked.
SOLUTION	<ul style="list-style-type: none"> • Insert a Smart Card into the display unit. The message on the screen will change to "Communicating With Meter." • Leave the Smart Card in the display unit until the "Communicating With Meter" message disappears and a beep sounds.
Invalid eCode! Try again	<ul style="list-style-type: none"> • Incorrect emergency code has been entered.
SOLUTION	<ul style="list-style-type: none"> • If unsuccessful, call SRP Customer Service at (602) 236-8855 for assistance.
Please insert your card!	<ul style="list-style-type: none"> • Smart Card has been removed from the display unit too soon.
SOLUTION	<ul style="list-style-type: none"> • Reinsert last Smart Card into display unit.
Re-enter eCode!	<ul style="list-style-type: none"> • The emergency code number is incorrect. Additional attempts to enter eCode will be allowed.
SOLUTION	<ul style="list-style-type: none"> • Re-enter eCode until "eCode Accepted" message appears.
Reinsert card!	<ul style="list-style-type: none"> • Bad contact between Smart Card and UDT. • Smart Card has been damaged.
SOLUTION	<ul style="list-style-type: none"> • Reinsert Smart Card to re-establish contact. • Try other Smart Cards in your possession. • Visit an SRP Customer Service Office to replace Smart Cards.
WARNING low credit	<ul style="list-style-type: none"> • Your energy credit is below the recommended amount.
SOLUTION	<ul style="list-style-type: none"> • Purchase additional energy credit immediately.

MESSAGE	CAUSE
WARNING out-of-date information	<ul style="list-style-type: none"> The display unit has not been able to refresh information for display selected.
SOLUTION	<p>If you have power in the house:</p> <ul style="list-style-type: none"> Check that the wall outlet is working by testing with another appliance. Check that the display unit is not plugged into a GFI, surge protector or switch-controlled outlet. Check that the plug is not loose. Check all circuit breakers. Reset if necessary. Relocate the display unit to another outlet in home. Push blue "Display Cycle" button. Reinsert last Smart Card. If display unit remains blank, visit an SRP Customer Service Office to replace display unit. <p>If you do not have power on in the house:</p> <ul style="list-style-type: none"> Check circuit breakers. Reset if necessary. Replace the battery. Place a new 9-volt alkaline battery in the display unit. If necessary, clean any corrosion on battery clips with rubbing alcohol and a cotton swab. Relocate the display unit to another outlet in home. Push blue "Display Cycle" button. Reinsert last Smart Card. If display unit remains blank, visit an SRP Customer Service Office to replace display unit.

PAYCENTER PROBLEMS

MESSAGE	CAUSE
Card not written	<ul style="list-style-type: none"> Credit purchase was not added to Smart Card.
SOLUTION	<ul style="list-style-type: none"> Call SRP Customer Service at (602) 236-8855 for assistance.
Meter not installed	<ul style="list-style-type: none"> Meter not installed or not activated.
SOLUTION	<ul style="list-style-type: none"> Call SRP Customer Service at (602) 236-8855 for assistance.
Transaction cancelled or Unable to process transaction	<ul style="list-style-type: none"> SRP PayCenter or SRP PayCenter network not working. Meter not installed.
SOLUTION	<ul style="list-style-type: none"> Wait 10 minutes and retry purchase. If unable to make purchase, call SRP Customer Service at (602) 236-8855 for assistance.

